



1/14/20 Image Formation 2

Analog to digital conversion



How to fix underexposure / overexposure:

- analog gain before digitization
0-5 → 0-255 to get proper range
- once you digitize, you can't get back any information that was lost
- happens to ALL pixels



During shutter: integrate light over time & area

$\int \text{light} dt dA$


- ① Discretization in intensity
- ② Discretization in space

doesn't help if we arbitrarily choose pixels
↳ relative intensity matters

issue: image sum

① overexposed b/c focus on bird

② underexposed bird b/c focus on sun



issue: walls between pixels


Sampling

Aliasing


bad b/c not just losing information
↳ we get incorrect information
indistinguishable from real information

solve using an optical lowpass filter

Going from 1 dimension to 2 dimensions:



Color



Bayer array


• 1/2 green

• 1/4 red


• 1/4 blue

↳ green val here is average of the greens surrounding it

Additive RGB



Subtractive CMYK



HSV (hue/saturation/value)
color white to color black to color

255 is red

↳ interpolation can add color artifacts @ sharp edges

Bayer artifact

algorithm to not interpolate across edges can fix it